

Project Title: DailyHunt


RollNo. 60

MAD & PWA Lab Journal


Experiment No.	01
Experiment Title.	To install and configure the Flutter Environment
Roll No.	60
Name	Pranav Titambe
Class	D15A
Subject	MAD & PWA Lab
Lab Outcome	LO1: Understand cross platform mobile application development using Flutter framework
Grade:	

AIM: - Installation and Configuration of Flutter Environment.


Step 1: Go to the official Flutter website: <https://docs.flutter.dev/get-started/install>




Step 2: To download the latest Flutter SDK, click on the Windows icon > Android



Step 3: For Windows, download the stable release (a .zip file).




Step 4: Extract the ZIP file to a folder (e.g., C:\flutter).



Step 5 :- Add Flutter to System PATH

Right-click on the Start Menu > System > Advanced system settings > Environment Variables. Under System Variables, find Path and click Edit.

Add the full path to the flutter/bin directory (e.g., C:\flutter\bin).



Step 6 :- Now, run the \$ flutter command in command prompt.

```
(base) PS C:\Users\prana> flutter
Manage your Flutter app development.

Common commands:

  flutter create <output directory>
    Create a new Flutter project in the specified directory.

  flutter run [options]
    Run your Flutter application on an attached device or in an emulator.

Usage: flutter <command> [arguments]

Global options:
-h, --help                Print this usage information.
-v, --verbose              Noisy logging, including all shell commands executed.
                           If used with "--help", shows hidden options. If used with "flutter doctor", shows additional
                           diagnostic information. (Use "-vv" to force verbose logging in those cases.)
-d, --device-id            Target device id or name (prefixes allowed).
--version                 Reports the version of this tool.
--enable-analytics         Enable telemetry reporting each time a flutter or dart command runs.
--disable-analytics       Disable telemetry reporting each time a flutter or dart command runs, until it is
                           re-enabled.
--suppress-analytics       Suppress analytics reporting for the current CLI invocation.

Available commands:

Flutter SDK
  bash-completion  Output command line shell completion setup scripts.
  channel          List or switch Flutter channels.
```

Step 7:- Run the \$ flutter doctor command. This command checks for all the requirements of Flutter app development and displays a report of the status of your Flutter installation

```
(base) PS C:\Users\prana> flutter doctor
Doctor summary (to see all details, run flutter doctor -v):
[✓] Flutter (Channel stable, 3.27.3, on Microsoft Windows [Version 10.0.26100.3037], locale en-IN)
[✓] Windows Version (Installed version of Windows is version 10 or higher)
[✓] Android toolchain - develop for Android devices (Android SDK version 35.0.1)
[✓] Chrome - develop for the web
[!] Visual Studio - develop Windows apps (Visual Studio Community 2022 17.12.4)
    × Visual Studio is missing necessary components. Please re-run the Visual Studio installer for the "Desktop
      development with C++" workload, and include these components:
        MSVC v142 - VS 2019 C++ x64/x86 build tools
          - If there are multiple build tool versions available, install the latest
        C++ CMake tools for Windows
        Windows 10 SDK
[✓] Android Studio (version 2024.2)
[✓] IntelliJ IDEA Ultimate Edition (version 2024.2)
[✓] VS Code (version 1.96.4)
[✓] Connected device (4 available)
[✓] Network resources


! Doctor found issues in 1 category.
(base) PS C:\Users\prana>
```

Step 8 :- Go to Android Studio and download the installer.


Download the latest version of Android Studio. For more information, see the [Android Studio release notes](#).

Platform	Android Studio package	Size	SHA-256 checksum
Windows (64-bit)	android-studio-2024.2.2.13-windows.exe Recommended	1.2 GB	7d93dd9bf3539f948f609b1968507bf1f502bfe965d2d44bd38a17ff26cb5dd3e
Windows (64-bit)	android-studio-2024.2.2.13-windows.zip No .exe installer	1.2 GB	855945962ff9b84ea49ce39de0bf4189dbf451ae37a6fab7999da013b046b7f7
Mac (64-bit)	android-studio-2024.2.2.13-mac.dmg	1.3 GB	acfbbe54d6ce8cf21f19b43510c7addcb9dde2824282f205fd1331be77d2e613
Mac (64-bit, ARM)	android-studio-2024.2.2.13-mac_arm.dmg	1.3 GB	688f8d007e612f3f0c18f316179079dc4565f93d8d1e6a7dad80c4cfc356df7
Linux (64-bit)	android-studio-2024.2.2.13-linux.tar.gz	1.3 GB	b7fe1ed4a7959bdaca7a8fd57461dbbf9a205eb23cc218ed82ed88e8b998cb5


Step 8.1: - When the download is complete, open the .exe file and run it. You will get the following dialog box




Step 8.2: - Select all the Checkboxes and Click on 'Next' Button.




Step 8.3: - Change the destination as per your convenience and click on 'Next' Button.




Step 8.4: - Follow the steps of the installation wizard. Once the installation wizard completes, you will get the following screen.





Step 8.5: - Go to Preferences > Appearance & Behavior > System Settings > Android SDK. Select the SDK Tools tab and check Android SDK Command-line Tools and Install it.




Step 9: - Open a terminal and run the following command

```
(base) PS C:\Users\prana> flutter doctor --android-licenses
Warning: Observed package id 'platform-tools' in inconsistent location 'C:\Users\prana\AppData\Local\Android\Sdk\platform-tools-2' (Expected 'C:\Users\prana\AppData\Local\Android\Sdk\platform-tools')
Warning: Observed package id 'platform-tools' in inconsistent location 'C:\Users\prana\AppData\Local\Android\Sdk\platform-tools-2' (Expected 'C:\Users\prana\AppData\Local\Android\Sdk\platform-tools')
Warning: Errors during XML parse:
Warning: Additionally, the fallback loader failed to parse the XML.rn...
Warning: Errors during XML parse:      ] 54% Fetch remote repository...
Warning: Additionally, the fallback loader failed to parse the XML.rn...
[=====] 100% Computing updates...
All SDK package licenses accepted.
```


```
(base) PS C:\Users\prana> flutter doctor
Doctor summary (to see all details, run flutter doctor -v):
[✓] Flutter (Channel stable, 3.27.3, on Microsoft Windows [Version 10.0.26100.3037], locale en-IN)
[✓] Windows Version (Installed version of Windows is version 10 or higher)
[✓] Android toolchain - develop for Android devices (Android SDK version 35.0.1)
[✓] Chrome - develop for the web
[!] Visual Studio - develop Windows apps (Visual Studio Community 2022 17.12.4)
    × Visual Studio is missing necessary components. Please re-run the Visual Studio installer for the "Desktop development with C++" workload, and include these components:
        MSVC v142 - VS 2019 C++ x64/x86 build tools
        - If there are multiple build tool versions available, install the latest
        C++ CMake tools for Windows
        Windows 10 SDK
[✓] Android Studio (version 2024.2)
[✓] IntelliJ IDEA Ultimate Edition (version 2024.2)
[✓] VS Code (version 1.96.4)
[✓] Connected device (4 available)
[✓] Network resources

! Doctor found issues in 1 category.
(base) PS C:\Users\prana>
```


Step 10: - Next, you need to set up an Android emulator. It is responsible for running and testing the Flutter application



Step 10.1: - Open Android Studio and go to Tools > AVD Manager. Create a new virtual device.





Step 10.2: - Click on the icon pointed into the red color rectangle. The Android emulator displayed as below screen



Step 11: - Now, install Flutter and Dart plugin for building Flutter application in Android Studio. These plugins provide a template to create a Flutter application, give an option to run and debug Flutter application in the Android Studio itself

Step 11.1: - Open the Android Studio and then go to File->Settings->Plugins. Now, search the Flutter plugin. If found, select Flutter plugin and click install



Step 11.2: - Restart the Android Studio

Step 12: - Go to File > New Project > Create Flutter Project, then select the project name and location, and click Next to proceed.

